









3G-1WLI
1.5" WALL LINIA
DIRECT
DIRECT/INDIRECT




⚠ FOR NEW CONSTRUCTION INSTALLATION ONLY

FIXTURE TYPES		INCLUDED COMPONENTS	
 1WLI PROFILE	Standalone Fixtures (2' to 8')		Continuous Runs (9' to 16')
	 INDIVIDUAL LENS		 STARTER ENDER LENS
Continuous Runs (17' and longer)		WALL MOUNT COMPONENTS	
 STARTER JOINER ENDER LENS		 WALL BRACKET BRACKET MOUNTING SCREWS	


INSTRUCTION KEY	INFORMATION
⚠ ADDITIONAL	INSTALLATION SHOULD ONLY BE PERFORMED BY A CERTIFIED ELECTRICIAN REFER TO LOCAL/NATIONAL CODES FOR PROPER INSTALLATION FAILURE TO FOLLOW INSTALLATION INSTRUCTION MAY VOID THE WARRANTY DO NOT TOUCH LEDS. LEDS MUST BE PROTECTED FROM MECHANICAL STRESS OR DEBRIS TURN OFF POWER DURING INSTALLATION OR SERVICING
i ATTENTION	
⚡ POWER ON	
⏻ POWER OFF	

OVERVIEW

3G - 1WLI




STARTER SECTION VIEW




ASYMMETRIC LENS ORIENTATION

3G - 1WLI - ASYMMETRIC LENS


ROOM SIDE DISTRIBUTION




ASYMMETRIC LENS



WALL GRAZING DISTRIBUTION




ASYMMETRIC LENS




WALL BRACKET LOCATIONS

FOR STANDALONE FIXTURES



FOR CONTINUOUS RUNS



❗ WALL BRACKETS ARE CENTERED BETWEEN ALL JOINED SECTIONS

IDENTIFICATION AND PREPARATION

ID LABEL

SECTION: **01 OF 03**

TYPE: **XX XX** CO-0000

ORDER TYPE ORDER NUMBER SECTION ID NUMBER

❗ IDENTIFY FIXTURE SECTIONS BY THE ID LABELS FOUND ON THE BOX INSIDE THE SECTIONS

ID LABEL









SECTION: **01 OF 03**
TYPE: **XX XX** CO-0000












STARTER


JOINER

ENDER










INSTALLING JOINER/ENDER














DRIVER SERVICING




LED SERVICING - DIRECT




LED SERVICING - INDIRECT


1 INDIRECT LENS REMOVAL




2



3




4




i PRESS DOWN ON TAB TO RELEASE WIRES FROM LED


5



6




7



RECONNECT WIRES AND SECURE LED BOARDS TO FIXTURE

8



LED SERVICING - INDIRECT - ASYMMETRIC AND WIDE SPREAD OPTIC

1

2

OPTIC

3

i PRESS DOWN ON TAB TO RELEASE WIRES FROM LED

4

LED BOARD

5

NEW LED BOARD

6

OPTIC

RECONNECT WIRES AND SECURE LED BOARDS TO FIXTURE

7

ROOM SIDE DISTRIBUTION

WALL SIDE

i APPLICABLE FOR INDIRECT ASYMMETRIC OPTIC INSTALLATION

WALL GRAZING DISTRIBUTION

WALL SIDE

i APPLICABLE FOR INDIRECT ASYMMETRIC OPTIC INSTALLATION