










3G-SKU24
24" SURFACE KUBO



i THE IMAGES SHOWN ARE FOR ILLUSTRATION PURPOSES ONLY AND MAY NOT BE AN EXACT REPRESENTATION OF THE PRODUCT


INCLUDED COMPONENTS	
 KUBO	

INSTRUCTION KEY	INFORMATION
 ADDITIONAL	INSTALLATION SHOULD ONLY BE PERFORMED BY A CERTIFIED ELECTRICIAN REFER TO LOCAL/NATIONAL CODES FOR PROPER INSTALLATION FAILURE TO FOLLOW INSTALLATION INSTRUCTION MAY VOID THE WARRANTY DO NOT TOUCH LEDS. LEDS MUST BE PROTECTED FROM MECHANICAL STRESS OR DEBRIS TURN OFF POWER DURING INSTALLATION OR SERVICING
 ATTENTION	
 POWER ON	
 POWER OFF	




DRIVER SERVICING

1




1A




DISCONNECT QUICK-CONNECT CABLE FROM LED BOARDS

2



REMOVE AND DISCONNECT DRIVER PLATE


3




SERVICE DRIVER AND REASSEMBLE FIXTURE

LED SERVICING

1




1A



DISCONNECT QUICK-CONNECT CABLE FROM LED BOARDS

2



REPLACE LED TRAY AND REASSEMBLE FIXTURE