





THE IMAGES SHOWN ARE FOR ILLUSTRATION ONLY AND MAY NOT BE AN EXACT REPRESENTATION OF THE PRODUCT

#### COMPONENTS



##### STANDARD CANOPY




##### CONDUIT FEED CANOPY



##### SEAMLESS CANOPY (FOR NEW CONSTRUCTION ONLY)
















#### 4" OCTAGONAL J-BOX REQUIRED FOR INSTALLATION












JUNCTION BOX (BY OTHERS)



INSTRUCTION KEY	INFORMATION
⚠ ADDITIONAL	INSTALLATION SHOULD ONLY BE PERFORMED BY A CERTIFIED ELECTRICIAN
ⓘ ATTENTION	REFER TO LOCAL/NATIONAL CODES FOR PROPER INSTALLATION
⚡ POWER ON	FAILURE TO FOLLOW INSTALLATION INSTRUCTION MAY VOID THE WARRANTY
⚡ POWER OFF	DO NOT TOUCH LEDS. LEDS MUST BE PROTECTED FROM MECHANICAL STRESS OR DEBRIS
	TURN OFF POWER DURING INSTALLATION OR SERVICING








6




CANOPY IS SUITABLE FOR  
MAXIMUM 3 CONDUIT FEEDS

## DRIVER SERVICING


1



2




3




## LED SERVICING

1




UNCLIP LOUVER FROM LED ASSEMBLY

2




UNCLIP CENTER CAP FROM LED ASSEMBLY

3




LOCATE CENTER SCREW

4




UNSCREW CENTER SCREW TO REMOVE LED ASSEMBLY

5




DISCONNECT QUICK-CONNECT CABLE FROM LED ASSEMBLY

6




CONNECT QUICK-CONNECT CABLE TO NEW LED ASSEMBLY

7



SCREW NEW LED ASSEMBLY INTO CYLINDER

8



9

